



GSM-START


LINKING MAN AND MACHINE



GSMS-PH4 QUICKSTART GUIDE

To use the unit a SIM-card is required, pre-pay SIM can be used.

1. Connect the supplied connection cable (2) to the wires (1) coming from the controller with the supplied 3M Scotchloks (3). Refer to the manual.



2. Make sure the SIM-card has balance and that the PIN-lock is disabled.
3. Install the SIM-card first then connect the unit to the connectioncable.
4. Wait (about 1 min) for the "SIG" led to start flashing every fourth second.
5. Send an SMS to the unit containing "PH0000CHECK", wait for a reply.
6. Get the app from Appstore or Google play for all commands.



GSMS Remote Control
Utilities



The complete manual can be found here: www.gsm-start.com/ph4en